


Medidas de parafuso - tabela de conversão

Parafuso Sextavado



Allen com Cabeça



Medida Nominal (mm)	Sextavado (mm)	Medida Nominal (pol)	Sextavado (pol)	Medida Nominal (mm)	Sextavado Interno (mm)	Medida Nominal (pol)	Sextavado Interno (pol)
M2	4	1/8	1/4	M1.4	1,3	8"	1/8
M2.2	4,5	5/32	1/4	M1.6	1,5	10"	5/32
M3	5,5	3/16	3/8	M3	5,5	3/16	3/8
M3,5	6	1/4	1/16	M2	1,5	1/4	3/16
M4	7	5/16	1/2	M2,5	2	5/16	1/4
M5	8	3/8	9/16	M3	2,5	3/8	5/16
M6	10	7/16	5/8	M4	3	7/16	3/8
M7	11	7/16	11/16	M5	4	1/2	3/8
M8	13	1/2	3/4	M6	5	9/16	7/16
M10	17	9/16	13/16	M8	6	5/8	1/2
M12	19	9/16	7/8	M10	8	3/4	5/8
M14	22	5/8	15/16	M12	10	7/8	3/4
M16	24	3/4	1 1/18	M14	12	1"	3/4
M18	27	7/8	1 5/16	M16	14	1 1/8	7/8
M20	30	1"	1 1/2	M18	14	1 1/4	7/8
M22	32	1 1/8	1 11/16	M20	17	1 3/8	1"
M24	36	1 1/4	1 7/8	M22	17	1 1/2	1"
M27	41	1 3/8	2 1/16	M24	19	1 3/4	1 1/4
M30	46	1 1/2	2 1/4	M27	19	2"	1 1/2
M33	50	1 3/4	2 5/8	M30	22		
M36	55	2"	3"	M33	24		
M39	60			M36	27		
M42	65			M42	32		
M48	75			M46	36		
M52	80			M56	41		
M55	85			M64	46		
M56	85			M72	55		
M60	90			M80	65		
M64	95			M90	75		
M68	100			M100	85		